



### Pilot hole guide for Plastic Press Base.

There is not much overhead clearance for the screw hole, so drilling straight down into the wood base is not recommended.

It is recommended to drill your pilot hole at an angle and on the black dot which is further back.

